



APPROVED PROCEDURE:

- 1) ISOLATE SECTION OF MAIN.
- 2) CUT OUT SECTION OF MAIN.
- 3) BEVEL EXISTING PVC MAIN.
- 4) INSTALL REPAIR/CLOSURE COUPLING ON EXISTING PVC MAIN.
- 5) INSTALL SECTIONS OF C900 OR C905 PVC INTO RUN ENDS OF TEE, WITH BEVELED ENDS OUT.
- 6) INSTALL TEE/GV AND SLIDE THE REPAIR/CLOSURE COUPLINGS TOWARDS TEE.
- 7) SEE OMWC FOR DISINFECTION PROCEDURES.

REV. DATE: 8/4/16

OILDALE MUTUAL WATER CO.	
POTABLE/DOMESTIC C900/C905 PVC PIPE REPAIR	
DATE: 8/1/13	PLATE No. 18