



APPROVED PROCEDURE:

- 1) ISOLATE SECTION OF MAIN.
- 2) CUT OUT SECTION OF MAIN.
- 3) BEVEL EXISTING PVC MAIN.
- 4) INSTALL REPAIR/CLOSURE COUPLING ON EXISTING PVC MAIN.
- 5) INSTALL SECTIONS OF C900 OR C905 PVC INTO RUN ENDS OF TEE, WITH BEVELED ENDS OUT.
- 6) INSTALL TEE/GV AND SLIDE THE REPAIR/CLOSURE COUPLINGS TOWARDS TEE.
- 7) SEE OMWC FOR DISINFECTION PROCEDURES.

REV. DATE: 8/4/16

OILDALE MUTUAL WATER CO.
 NON-POTABLE/IRRIGATION
 TIE-IN DETAIL
 C900/C905 PVC PIPE

DATE: 8/1/13

PLATE No. IRR-19